

# ***Wireless Gauge Reader Mounting Adapters***

*(GRA and GRP Series)*



GRA Series Mounting Adapters  
GRP Series Adhesive Rings  
Process Gauge Adapters  
Magnehelic Adapters



**CYPRESS**  
ENVIROSYSTEMS™

# 1.0 How to Attach a WGR to a Gauge

Select Attachment Method According to Gauge Type

## Method A Conventional

WGR Adapter clamps around outside of gauge



## Method B Flush (Panel) Mounted or Large Diameter Gauge

WGR adhesive adapters affix to panel or gauge lens



# How to attach a WGR to a Gauge – Method A

**Method A – for conventional gauges up to 4” outside diameter**



- 1) Attach **Rubber Shims** to gauge (as needed)



- 2) Attach **WGR Mounting Adapter** to gauge



- 3) Note alignment mark on **WGR Mounting Adapter** should be at upper left corner.
- 4) Tighten **Hose Clamp** to hand torque using slot screwdriver

# How to attach a WGR to a Gauge – Method A

## Method A – continued



- 5) Attach **WGR Sensor** to WGR Mounting Adapter using 1/8 turn quickdisconnect.

Note: start with WGR Sensor rotated counterclockwise 1/8 turn and attach to WGR Mounting Adapter. Then turn WGR Sensor clockwise till you hear a click to lock the quick disconnect.



Fully Mounted  
**WGR Assembly**

# How to attach a WGR to a Gauge – Method B

Method B – for flush (panel) mounted gauges, or gauges with outside diameter greater than 4" diameter



Large  
Diameter  
Gauge

UHB  
Double  
Sticky  
Tape

WGR  
Adhesive  
Ring

WGR  
Mounting  
Adapter &  
Hose Clamp

WGR  
Sensor



# How to attach a WGR to a Gauge – Method B

## Method B – continued -1



- 1) Using UHB tape, attach **WGR Adhesive Ring** to:
  - a. Gauge Lens  
(if mounting on large diameter gauge)
  - b. or front panel  
(if mounting on panel mounted gauge)



- 2) Attach **WGR Mounting Adapter** to WGR Adhesive Ring



- 3) Note alignment mark on **WGR Mounting Adapter** should be at upper left corner.
- 4) Tighten **Hose Clamp** to hand torque using slot screwdriver

# How to attach a WGR to a Gauge – Method B

## Method B – continued - 2



- 5) Attach **WGR Sensor** to WGR Mounting Adapter using 1/8 turn quick disconnect.

Note: start with WGR Sensor rotated counterclockwise 1/8 turn and attach to WGR Mounting Adapter. Then turn WGR Sensor clockwise till you hear a click to lock the quick disconnect.



Fully Mounted  
**WGR Assembly**

# Different Size Adapters Available

## WGR Mounting Adapters

| Part Numer  | Description  |
|-------------|--|
| GRA-110-005 | WGR Adapter, for gauges from 1.600" to 1.955" Outside Diameter |
| GRA-110-010 | WGR Adapter, for gauges from 1.955" to 2.390" Outside Diameter |
| GRA-110-015 | WGR Adapter, for gauges from 2.390" to 2.822" Outside Diameter |
| GRA-110-020 | WGR Adapter, for gauges from 2.820" to 3.285" Outside Diameter |
| GRA-110-025 | WGR Adapter, for gauges from 3.285" to 3.715" Outside Diameter |
| GRA-110-030 | WGR Adapter, for gauges from 3.715" to 4.123" Outside Diameter |
| GRA-110-035 | WGR Adapter, for gauges from 4.181" to 4.860" Outside Diameter |

## WGR Adhesive Rings

| Part Numer  | Description  |
|-------------|--|
| GRP-100-005 | Adhesive mounting ring for panel mount - 2.0" OD   |
| GRP-100-010 | Adhesive mounting ring for panel mount - 2.3" OD   |
| GRP-100-015 | Adhesive mounting ring for panel mount - 3.625" OD |
| GRP-100-020 | Adhesive mounting ring for panel mount - 4.0" OD   |
| GRP-100-025 | Adhesive mounting ring for panel mount - 4.375" OD |
| GRP-100-030 | Adhesive mounting ring for panel mount - 4.625" OD |
| GRP-100-035 | Adhesive mounting ring for panel mount - 5.625" OD |



## Special Case: Magnehelic Gauges





## **Special Case: Process Gauge Adapter**

# Process Gauge Adapter

GRA-110-130: Adapter for process gauges 4.5 inch diameter, with tapered sides.  
Important: Must have access to back of gauge to use this adapter. NOT for panel or flush mounted gauges.





## **Special Case: Magnehelic Adapter**

# Magnehelic Gauge Adapter

GRA-110-135: Adapter for Dywer Magnehelic and Photohelic Gauges.

Important: Must have access to back of gauge to use this adapter. NOT for panel or flush mounted gauges.

