Wireless Pneumatic Thermostat (WPT) Training Program

www.CypressEnvirosystems.com



WPT Training Modules





WPT Training Modules





WPT Features and Benefits

EXISTING LEGACY STAT

Honeywell Warm 70 30 40 50 50 70

DDC in 20 Minutes!

- Manual Setpoint Control
- No Remote Readings
- No Diagnostics
- Manual Calibration Required

CYPRESS ENVIROSYSTEMS WIRELESS PNEUMATIC THERMOSTAT



- Remote Wireless Setpoint Control
- Remote Monitoring of Temperature & Pressure
- Pager/Cell Notification of Excursions
- Automatic Self-calibration
- Programmable Zone/Night Setback Control
- Occupancy Override
- Enables Demand Response strategies
- BACnet Interface to BMS
- Compatible With Existing Johnson, Honeywell, Siemens, Robertshaw
- More than 2yr battery life

Get the benefits of Direct Digital Control (DDC) in less than 20 minutes



Cypress Confidential

Proven Wireless + Pneumatic Technology

- Uses proven pneumatic bi-metallic strip technology for room temperature control
- We added advanced electronics to remotely control setpoint, and monitor temperature, branch pressure, and battery status.
- If battery fails and electronics stop working, unit will function just like a traditional pneumatic stat



Advanced digital electronics for wireless control, monitoring and diagnostics.

Proven embedded bi-metallic strip technology for room temperature control



WPT = Conventional Pneumatic Thermostat + Virtual Thumb

Cypress Wireless Communications

- Uses Cypress Semiconductor wireless technology – first deployed over six years ago, with over 25 million nodes in use today
- Hybrid mesh wireless architecture provides coverage for most buildings and industrial sites – already in use by many Fortune 500 customers
- Up to 240 WPT's and/or Repeaters supported per Hub
- Note: Do not use where cell phones or WiFi are prohibited (i.e. hospital operating rooms), or in environments requiring temperature validation



2.4 GHz DSSS radios, +20dBm (100mW) peak output power

Proven wireless technology applied for legacy retrofit application



Selected Customer Sites Using Cypress Wireless



CYPRESS ENVIROSYSTEMS Stanford, Novellus, Micrel sites available for site visits upon request

Cypress Confidential

Cypress Envirosystems Wireless Products Installed in Industrial Environment















Directly Replaces Existing Thermostats

 Directly replaces most existing pneumatic thermostats from Honeywell, Johnson Controls, Siemens, Robertshaw etc.



 Comes with a universal wall mounting bracket, and connects to existing main and branch pipes in minutes.





User Interface and Connectivity via BACnet

- The WPT Hub has a built-in web based user interface for configuration and basic operations
- The WPT Hub may also be connected to existing automation systems via BACnet/IP using a simple CAT 5 Ethernet cable
- BACnet compatible controllers (e.g. JCl Network Integration Engine) can gather data points and control setpoints, and provide a user interfcae
- Users do not need a separate operator station or learn a new interface.





BACnet Compatibility Testing

VENDOR	BAS	TEST PARTNER	LOCATION
ALERTON	BACtalk	Syserco	Fremont, CA
AUTOMATEDLOGIC*	ALC	ACCO Engineered Systems	San Leandro, CA
Honeywell	Excel, <u>Tridium</u>	Pending	
Johnson Controls	<u>Metasys</u>	RSD-Total Control JCI Sensor Products	San Jose, CA Milwaukee, WI
SIEMENS	Apogee	Siemens Building Technologies	Hayward, CA
t.a.c	Andover Continuum	EMCOR Integrated Solutions	Pleasanton, CA

Cypress Envirosystems and its logo are trademarks of Cypress Systems. The name of any other company, products, or services mentioned herein are for identification purposes only and may be trademarks, registered trademarks, or service marks of or may be copyrighted by their respective holders. @2008 Cypress Systems_ All rights reserved.



Key Components of WPT System



Server (WPT-800-SWEB/ WPT-800-SBAC)

Contains Configuration tools, remote monitoring & control application, BACnet interface, DR Interface, and Web services



USB Hub (WPT-800-HUSB)

Attaches the WPT Wireless network to the server

Wall powered repeater

(WPT-800-RWAL)

Extends the WPT wireless range



Battery powered repeater (WPT-800-RBAT)

To be used in places where there is no power socket available



WPT Node (WPT-800-TXXX)

Replaces the existing pneumatic stat. Available in single/dual pipe with direct/reverse action



WPT Training Modules





Recommended Installation Workflow

1) Start with WPT Wireless Network Planning

- Note the types of stats to be retrofitted
- Perform site survey to determine where to place repeaters, hub and server
- Select the type of repeaters to use
- Determine the number of repeaters required
- 2) Install and configure Server and Hub
 - The Hub and Server should be setup first as the core of the network
 - Configuration tool will generate unique ID's to assign to each WPT and repeater
- 3) Install and configure Repeaters
 - Install the repeaters
 - Configure repeaters to setup WPT wireless network
- 4) Install WPT's
 - Physically remove old thermostats and connect and mount WPT's in their place
 - Configure WPT's to communicate with the wireless network



WPT Training Modules





WPT Wireless Network Planning Overview

- Wireless network planning involves selecting right location for repeaters and hub
- Depending on the building, the wireless range and the number of repeaters required may differ
- More than one hub may be used for larger sites. Each hub and its associated repeaters are considered a separate network.
- This training module addresses:
 - How to maximize wireless range
 - How to select the type of repeater
 - How to estimate number of repeaters required
 - How to use the wireless survey tool





Guidelines for Maximizing Wireless Range



Wireless Performance in Buildings

- Cypress wireless has been installed in many different types of sites from lowrise office buildings to high rise commercial buildings to industrial plants.
- Typical wireless ranges for a single "hop" are:

Line of Sight	300 ft open halls 150 ft in open office floor 100 ft in corridors
Sheet Rock / Dry wood	100 ft, through five walls
Brick Walls	60 ft, through three walls
Ceilings	25 ft , through single ceiling

• Repeaters allow for multiple "hops" which extend the communications range of the system.



Factors Reducing Wireless Range

- Wireless range is particularly affected when metal obstacles are in the line of transmission.
- A solid sheet of metal presents the greatest obstacle, while rebar reinforced concrete is less.
- Try to note the following objects and avoid in the line of transmission:
 - Hollow lightweight walls filled with insulating metal foil
 - Office equipment and furniture such as book shelves, file cabinets, metal partitions, computer racks
 - Metal reinforced concrete walls, pillars and columns
 - Glass walls with metal coating
 - Plumbing and electrical risers
 - Elevator shafts and stairwells
 - Mechanical and electrical equipment rooms

Bigger the metal obstacles in the transmission path shorter the wireless coverage



Where to place Repeaters and Hub

DO'S

- Place the hub in a central location on the site with power and preferably nearby LAN drop
- Place repeaters in a central location in a room
- Mount repeaters and hubs at eyelevel or higher to avoid furniture obstructions
- Place the wall powered repeaters directly above each other when transmitting to adjacent floors
- Place wall powered repeaters every 50 ft to improve wireless path redundancy

DON'Ts

- Avoid solid metal obstacles in the line of transmission
- Don't install repeaters along the same side of the wall as that of the WPT (wireless coverage is better in front vs. side of WPT)
- Don't mount hubs or repeaters within 3 ft of computers or A/V equipment (which may produce interfering radio waves)



Selecting the Proper Type of Repeater



Two Types of Repeaters Available

Battery Powered Repeater

Wall Powered Repeater





Selecting the Right Repeater

- Battery Powered repeaters are convenient, but come with limitations. As a general rule, use Wall Powered repeaters where possible.
- The following table compares the features of the two types of repeaters.

	Wall Powered Repeater (RWAL)	Battery Powered Repeater (RBAT)	Comments
Power Source	110VAC wall outlet	4 x CR123 Lithium Batteries	RWAL plugs into the wall socket via power cord. RBAT uses replaceable battery cells.
Battery Changeout	No change out needed	2 yrs (typical)	WPTs connected to a RBAT consume slightly more power than those connected to a RWAL.
Maximum number allowed in a network	16	2	RBAT's in close proximity may degrade the reliability of wireless communication.
WPTs supported per repeater	15	8	
Repeater-to-Repeater connectivity	Can connect with WPT and other RWAL's or RBAT's	Can connect with WPT and RWAL's, but not other RBAT's	RBAT can be used only at the periphery of a WPT wireless network, not in the middle of a chain of repeaters.
Floor-to-Floor connectivity	Yes	No	RBAT cannot be used to extend wireless communications from one floor to another.

RWAL is the primary choice of repeater; use RBAT only as a last option



Typical Layout of WPT Network in a Building



WPT Wireless Network in a Typical Office Building



Typical layout of WPT Network in a building





Thermostats



WPT Wireless Network in a typical multi-floor office building

Guidelines for Estimating the Number of Repeaters Needed



Estimating Number of Repeaters Needed

GUIDELINES/RULES OF THUMB:

- Allocate one RWAL for every 15 WPTs on a floor depending on the wireless range
- Use RWAL's (not RBAT's) for extending the WPT wireless network across different floors
- Use RBAT's only at the periphery of the WPT network. Do not use them in the middle of the repeater chain
- Ensure that every RBAT has a RWAL or Hub within its coverage area



Using the Wireless Survey Tool



Wireless Range Tester

- The wireless range tester is used to determine the repeater locations
- The wireless range tester consists of a battery powered *Transponder* and *Tester*
- The *Transponder* and *Tester* can be turned ON by simply inserting the batteries and pressing any key
- The wireless range tester does a wireless discovery process (handshake) as per the WPT Wireless protocol to determine the wireless coverage reliably
- The *Tester* can be also used to check for the multiple RF paths in an installed network



Transponder







Installing the Batteries







Using the Wireless Range Tester

- Identify potential location for the Repeaters and Hub as per the location selection guide and the floor plan
- Keep the *Transponder* at the target location of the Repeater / Hub
- Check the signal strength at each of the thermostat locations by pressing the

 key on the Tester
 - The *Tester* displays the signal strength on a scale of 0 100
 - Above 75 indicates excellent coverage
 - Above **60** indicates good coverage
 - Below **50** indicates limited coverage; consider additional repeaters or changing the location of the repeaters
 - If the wireless coverage is bad, the discovery process will fail; LCD displays dF
 - To ensure consistent wireless coverage, check for signal strength multiple times
- In an installed network, availability of multiple RF paths can be verified by pressing the vec key on the *Tester*
 - The *Tester* displays the ID of the repeater primary repeater it is talking to
 - Press key again to see the ID of the secondary repeater available
- Press **OVR** key on the *Tester* to exit the wireless path display







WPT Training Modules





WPT Hub and Server Setup Overview

- One USB-Hub and Server is required per WPT Wireless Network
- The Hub is the receiver/transmitter for the WPT wireless signals. The Server provides data storage and the User Interface
- There may be more than one USB-Hub & WPT-Server per site (if necessary due to size of site)
- Each Hub may support up to 240 WPT's and/or repeaters
- The Server uses industry standard Windows XP/Pro operating system and includes optional BACnet/IP interface
- This training module addresses:
 - How to install and configure WPT Server
 - How to install and configure a Hub
 - How to verify a Hub is working correctly





WPT Server Setup





Accessing WPT Server

- The WPT Server is configured with a default IP: 10.1.10.8
- WPT Server IP Address can be changed by connecting from any machine in the network using Microsoft Remote Desktop connection (Start -> All Programs -> Accessories -> Remote Desktop Connection)
 - The default IP address : 10.1.10.8
 - Default username: (please see training coordinator)
 - Default password: (please see training coordinator)
- If the WPT server is not connected to the LAN, use a network cable to directly connect from a laptop
 - Make sure that the laptop is configured with a static IP : 10.1.10.x
- The WPT server can also be directly accessed by connecting a monitor, keyboard and mouse
- WPT Web Portal has the setup tool for generating the IDs required for configuring the Hub, Repeaters and WPTs
- The WPT Web Portal can be accessed using *Microsoft Internet Explorer* from PC connected to the WPT Server



Accessing the WPT Web Portal

• Access the WPT Web Portal using the URL:

http://10.1.10.8/WPtWebApp



- Enter the default username : (please see training coordinator)
- Enter the default admin password : (please see training coordinator)
- Click Log in


Creating Network, Repeater and Node IDs

Cone Monitor S	setup 1	User Administration	Alarm	Schedule	Advanced	Help
Hub Repeater Node	Node Group View	v Site Configuration				
WPT Hub Configura	tion					
Hub/Network I	ID 1	2				
Locatio	on WPT beta site	3				
	Update 4					

Create Network ID

Zone N	lonitor	Setup	1	User Ad	ministration	Alarm	Schedule	Advanced	Hel
Hub	Repeate	r Node Nod	de Group	View Site Cont	iguration				
WPT	Repea	ter Configur	ation						
	Repe	eater Type B	attery Pov	wered 🔽 3					
	R	epeater ID B1	1	4					
	Location 1st Floor 5]				
			Add	6					
_									
	Delete	RepeaterID	TypeID	RepeaterType	NetworkID	Location			
<u>Edit</u>	×	10	1	RWAL	1				
<u>Edit</u>	X	11	1	RWAL	1				
<u>Edit</u>	×	B0	0	RBAT	1				

Create Repeater ID

one N	donitor		Setup 1	Use	r Administra	tion	Alarm	Schedule	Advanced	He
Hub	Repea	ter Node	Node Grou	p View Site	Configuratio	on				
WPT Node Configuration										
		Node ID	B705		3					
Node Name 4										
		Location			5					
	E	BACnet ID			6					
Т	emp. C	Offset (°F)	0		+/-4 °F) 7					
			Add	8						
_										
	Delet	e NodelD	NetworkID	NodeName	Location	BACne	etID OffsetValue			
Edit	×	1101	1	PR 11-HUB	cubicle 5026	1101	0			
<u>Edit</u>	X	1102	1	PR 11-HUB	cubicle 5026	1102	0			
<u>Edit</u>	×	1103	1	PR 11-HUB	cubicle 5026	1103	0			
				Crea	ate No	ode				



WPT Wireless Network Settings Report

• WPT Wireless Network configurations summary can be viewed and printed from the WPT Web portal

								···, <u></u>
Zone Moni	tor Setup	1	User Administration	Alarm	Schedule	Advanced	l Help	
Hub Rep	eater Node Node Group	View	Site Configuratio					
🗗 🍊	₩ ◀ ▶ ₩ 1/1		Main Report 🗸	Business Objects				
			WPT Network Set	ttings				
N	D:1 Location:WPT beta site	•		-				
Rep 3								
ID	RepeaterType	•		Location				
10	Wall Powered							
11	Wall Powered							
B0	Battery Powered							
B1	Battery Powered							
Nodes								
ID	Node Name			Location				
1107	PR-11 HUB12			Cubicle 5026				
1202	PR12-PR13133	1		Cubicle 5022				
1203	PR12-PR132			Cubicle 5022				
1204	PR12-PR13			Cubicle 5022				
1301	PR13							

• Use this report for configuring the Hub, Repeaters and Nodes



Installing USB Hub



USB Hub (HUSB) Installation

1. Mount the Hub on to a wall at eye level

2. Turn ON the server and connect the Hub to the server's USB port







Programming Hub Network ID



Press all three keys starting from top-middle-bottom and hold them for 1 second to enter programming mode



Network ID Programming Mode

- Network ID is a single digit hexadecimal number (1,2...9,A,B,C,D,E,F) generated using the WPT Web Portal, as discussed in module 2.2
- °F is ON
- Use ▲ ▼ key to enter the Network ID
- Press **OVR** key to confirm and exit the programming mode
- <u>Note 1</u>: The Hub is factory configured with Network ID 1. You don't need to program the Hub, if your Network ID is 1
- <u>Note 2</u>: The Hub will exit the programming mode automatically if there is no action for 1 minute



Troubleshooting the Hub

Error Code	Possible Cause	Solution
E2	Radio Error – Not able to send/receive data	Restart the unit with removing and inserting the USB Cable to the WPT Server If the error continues the device requires replacement
E3	Ping Error – Due to a new RF interference source in the area	Track down and eliminate the new source of RF interference or change the location of the Hub
E4	Connect Error – Not able to connect to the nearest Repeater	If this error occurs after successful installation, the HUSB will auto recover after couple of refresh cycles If the error persists for more than few hours, add a repeater in the zone
E5	USB Error – Not able to communicate with the WPT Server	Check USB cable Change to a different USB port If problem persists, replace the HUSB



WPT Training Modules





Installing Repeaters



Wall Powered Repeater (RWAL)





Mounting the RWAL

Connecting the RWAL to the power socket

Note:

- 1. consider using a wire mold to conceal the power cable
- 2. Use an optional extension cable to reach out to a power socket located away from the RWAL



Battery Powered Repeater (RBAT)





Installing Batteries for the RBAT





Programming Repeater Network ID



Press all three keys starting from top-middle-bottom and hold them for 1 second to enter programming mode



Network ID Programming Mode

- Network ID is a single digit hexadecimal number (1,2...9,A,B,C,D,E,F) generated using the WPT Web Portal, as discussed in module 2.2
- °F is ON and Network ID flashes
- Use ▲ ▼ key to enter the ID
- Press OVR key to confirm
- <u>Note 1</u>: The Repeater is factory configured with Network ID 1. You can skip the Network ID programming by pressing the **OVR** key
- <u>Note 2</u>: The Repeater will exit the programming mode automatically if there is no action for 1 minute



Programming Repeater ID



• Repeater ID is a two digit [D2 D1] hexadecimal number (0,1,2...9,A,B,C,D,E,F) generated using the WPT Web Portal, as discussed in module 2.2

•°C is ON and Corresponding bar of the battery indicator flashes

- Use \checkmark vev to enter the Repeater ID
- Press OVR key to confirm

•Note: The Repeater will exit the programming mode automatically if there is no action for 1 minute



Troubleshooting the Repeaters

Error Code	Possible Cause	Solution
EO	Discovery Error – Not able to connect to nearest Repeater or Hub	Retry discovery by pressing any key Check if Repeater or Hub is working Try resetting the Repeater Try with a different position of the repeater/ Hub if feasible
E1	Time Synchronization Error – Not able to synchronize the RWAL time with the wireless network	If this error occurs after successful commissioning of the system, RWAL will recover from this error within coupe of refresh cycles
E2	Radio Error – Not able to send/receive data	Restart the unit with removing and inserting the battery or unplugging and plugging the A/C power adaptor If the error continues the device requires replacement
E3	Ping Error – Due to a new RF interference source in the area	Track down and eliminate the new source of RF interference or change the location of the Hub
E4	Connect Error – Not able to connect to the nearest Hub or Repeater	If this error occurs after successful installation, the Repeater will auto recover after couple of refresh cycles If the error persists for more than few hours, add a repeater in the zone



WPT Training Modules





WPT Wall Thermostat Installation Overview

- Installing a WPT and configuring it for wireless communication should take less than 15 minutes
- This training module addresses:
 - How to physically install the WPT
 - How to install the batteries
 - How to turn on and configure the WPT using the front panel
 - Calibrating the pneumatic stat



Mounting the WPT



Installing the WPT – Step 1

Remove the existing thermostat and wall plate





Mount universal adapter plate, connect pipes to WPT and mount WPT to wall





Installing the Batteries



Installing the Batteries for WPT









Configuring the WPT for Wireless Communications



Programming WPT Network ID



Press all three keys starting from top-middle-bottom and hold them for 1 second to enter programming mode Network ID Programming Mode

OVR

- Network ID is a single digit hexadecimal number (1,2...9,A, B,C,D,E,F) generated using the WPT Web Portal, as discussed in module 2.2
- °F is ON and Network ID flashes
- Press **OVR** key to confirm
- <u>Note 1</u>: The WPT is factory configured with Network ID 1. You can skip the Network ID programming by pressing the **OVR** key
- <u>Note 2</u>: The WPT will exit the programming mode automatically if there is no action for 1 minute



Programming WPT Node ID



- Node ID is a four digit [D4 D3 D2 D1] hexadecimal number (0,1,2...9,A,B,C,D,E,F) generated using the WPT Web Portal, as discussed in module 2.2
- °C is ON and Corresponding bar of the battery indicator flashes
- Press OVR key to confirm
- Note 2: The WPT will exit the programming mode automatically if there is no action for 1 minute



Troubleshooting the WPT

Error Code	Possible Cause	Solution
EO	Discovery Error – Not able to connect to nearest Repeater or Hub	Retry discovery by pressing any key Check if repeater or Hub is working Try resetting the repeater. Try with a different position of the Repeater/ Hub if feasible
E1	Time Synchronization Error – Not able to synchronize the WPT time with the wireless network	If this error occurs after successful commissioning of the system, WPT will recover from this error within coupe of refresh cycles
E2	Radio Error – Not able to send/receive data	Restart the unit with removing and inserting the battery If the error continues the device requires replacement
E4	Connect Error – Not able to connect to the nearest Hub or Repeater	If this error occurs after successful installation, the WPT will auto recover after couple of refresh cycles If the error persists for few hours add a repeater in the zone



Calibrating the WPT



Calibrating the Pneumatic Stat

- Remove the front cover of WPT
- Note down the ambient temperature displayed on the LCD.
- Set the setpoint manually using the ▲ or ▼ key to the ambient temperature.
- Set the WPT to branch line pressure measurement mode as described in section 3.1.
- Use a 1/16" hex Allen wrench and turn the calibration set screw on the thermostat lever until the desired pressure is displayed on the LCD.
- Press **OVR** key to exit pressure measurement mode.
- Replace the WPT front cover.
- Set the setpoint to the desired value using the \blacktriangle or \triangledown key





Adjusting the Throttling Range

- WPT is factory calibrated for 3°F throttling range
- Remove the front cover of the WPT
- Gently slide the black throttling range adjuster to the appropriate location
- Verify the calibration after the throttling range adjustment
- Replace the front cover of the WPT





WPT Training Modules





WPT LCD Display



WPT LCD Display



WPT Operation

- Change Setpoint
 - Press the ▲ or ▼ key once to view the current set point along with the set point indicator
 - Press the \blacktriangle or \blacktriangledown key to change the set point value
 - After the desired set point is set, the LCD displays reverts to show the current temperature
- Set / Reset Occupancy Override
 - Press the **OVR** key to activate the occupancy override
 The LCD display flashes the override duration in hours
 - Press the \blacktriangle or \blacktriangledown key to change the override duration to desired value
 - LCD displays the Occupancy Override Indicator during the Override period
 - To cancel the Occupancy Override mode, press the OVR key and the Occupancy Override Indicator will disappear







Lock/Unlock WPT LCD Keys

- Locking the LCD keys prevents user from changing the setpoint and other configuration information of WPT
- Locking the LCD keys
 - Press the ▲ and ▼ keys simultaneously for 2 seconds
 - The key is locked and the LCD displays "LC" for 2 seconds
 - When the keys are locked user won't be able to use the keys on the stat to change the setpoint or Occ Override
 - When the Keys are locked and if the user tries pressing any keys, "LC" appears to indicate that keys are locked
- Unlocking the LCD keys
 - Press the ▲ and ▼ keys simultaneously for 2 seconds
 - The key is locked and the LCD displays "UL" for 2 seconds
- <u>Note</u>: The LCD Keys can be locked/unlocked from the WPT Server as well.







Diagnostic Info

- To view diagnostic info press and hold ▼ key & **OVR** keys simultaneously for 2 seconds
- The LCD displays '**dt**' to indicate the diagnostic mode
- Press **OVR** once to view the firmware Version of the WPT
- Press **OVR** for the second time to view the current branch pressure in PSI
- Press **OVR** to exit the diagnostic page
- <u>Note</u>: The WPT will exit the diagnostic mode automatically if there is no action for 1 minute







Force Discovery

- Force discovery helps in establishing the Wireless connectivity during installation / troubleshooting
- To initiate Force Discovery, user must enter into the diagnostic mode by pressing and holding ▼ key & **OVR** keys simultaneously for 2 seconds
- The LCD displays '**dt**' to indicate the diagnostic mode
- Press **A** once to enter the Force discovery mode; The LCD displays '**Fd**'
- Press ▲ again to start the Force Discovery; After successful force discovery the WPT will return to normal operating mode
- If the WPT is not able to establish wireless connection with a Repeater/Hub, LCD will display '**Df**' to indicate discovery failure
- When Force Discovery fails, use a WPT Wireless Range Tester to check the signal strength and install an additional Repeater, if required







Changing Batteries









WPT Training Modules




User Administration

• Adding user

Zone Monitor	Se	tup	User Administratio	n Alarm	Sc	hedule:	Advanced	Help
User User Gr	oup		1					
WP User A	dministra	tion						
User ID		john	3 Em	ail ID	john@wpt	.com		
User Name		John Wilson	Pho	ne	40880687	43		
Password		wpt123	Pho	one Prefix	11			
User Type		Read Only	 Loc 	ation	WPT			
			4 Add Can	cel				
Delete	Userid	UserName	Email	Phone	PhonePrefix			
Edit 🔀	admin	Administrator	ragu@cypress.com	4088068743	12			
Edit 🗙	ragu	Ragunath R	ragu@cypress.com	4088068743	0			
Edit 🗙	readonly	Read Only User	ragu@cypress.com	4088068743	12			

• Creating User group

Zone Monitor	Setup	User Administration	Alarm	Schedule	Advanced	Help
User User Group		1				
WPT User Group	/iew					
User Group Na	me Supervisor 1	3				
Available Us Read Only User supervisor WPT Administrator	Add Cancel	ected Users gunath R ninistrator				
Delete Group Edit X test12 Edit X test1	DName 34					



Zone Monitoring

• WPT Dashboard

Z	Cone Monitor 1 Setup		Us	er Adn	ninistration	Alarm		Schedule	Adv	anced	Help	
z	one Groups	DashBoa	rd Cha	inge S	etpoint Rep	oorts					P	
	ALL	Refrest	Refresh Acknowledge									
Canteen BPR Node 4 - (B104)	NodelD	Alarm	АСК	Node Name	Setpoint (°F)	Zone Temp (°F)	Branch Pressure (PSI)	Battery Level(%)	Occupancy Override	Time		
	BPR Node 1 - (B701)	1107	\$		PR-11 HUB12	75	72	0	100	OFF	11/18/2008 5:48:31 PM	
8	Test group1	1202	۲		PR12- PR13133	81	74	0	100	OFF	12/16/2008 9:47:35 PM	
	- PR-11 HUB12 - (1107) - PR12-PR13133 - (1202)	1203	₹		PR12- PR132	81	74	0	25	OFF	12/16/2008 9:32:34 PM	
6	PR13 - (1301)	1204	۲		PR12- PR13	81	73	0	100	OFF	12/16/2008 9:54:20 PM	
	PR-11 HUB12 - (1107)	1301	*		PR13	72	72	0	100	ON	12/12/2008 1:36:12 PM	
	(4606)	1302	۲		PR13- PR12	81	72	0	25	OFF	12/14/2008 11:10:52 AM	

- Changing setpoint
 - Setpoint can be changed for selected zone or for all zones in a group

Zone Monitor 1 Setup	User Administration	Alarm	Schedule	Advanced	Help
Zone Groups	DashBoard Change Setpoint Re	ports			م
₽- ALL	Group Name 2	Conference Rooms			
÷ <mark>Conference Rooms</mark> 3	Current Setpoint (°F)				
- PR12-PR13133 - (1202)	Current Zone Temp. (°F)				
- PR12-PR132 - (1203)	Setpoint Temperature (*F)		4		
PR12-PR13 - (1204)	5 Undate	Cancel			
- Canteen	o opene				
- Test group1					
⊕- testgroup3					



Configure schedule

1. Configure Occ/unocc setpoints

2. Configure weekday schedule

3. Configure weekend schedule

4. Configure holiday schedule



5. Configure special day schedule









Configure Alarm

1. Configure Alarm limits

Zone Monitor	Setup	User Administra	ition	Alarm 1	Schedule	Advanced	Help
Alarm Limits Alarm	Notification						
Valid Secont		Zone Tem	iperati	ure Limit		1	
Min. Value 55	(*F) 3	High Limit:	Setpo	int + 2	("F)		
Max. Value 85	(°F) 4	Low Limit:	Setpo	iint - 2	("F)		
Battery Limit Alarm Limit 25	(%)]	[5 Update	•		

2. Configure Notification

Zone Monitor	Setup	User Administration	Alarm 1	Schedule	Advanced	Help
Alarm Limits Alarm	n Notification					
Group Name	2	ALL 🔽 3				
Alarm Type		Temperature 🛛 🖌 4]			
User Group		Supervisor 1 💌 🚦				
	Add 6					
Delete ID N	ode Group Name	Alarm Type User Group				
Edit 🗙 6 Al	L.	Temperature Supervisor 1				



View Trend

Zone Monitor 1	Setup	User Administration	Reports	Help	
Group Structure	DashBoard Change Setp	oint Configure Notification	Configure Schedule	Trend	٩ (
⊕- <mark>ALL</mark>	Node ID 0101	✓ 3		2	
- Conference Rooms	Start Date 11/13/	2006 4	5 End D	late 12/18/2008	::: : :
- 3rd Floor	View Report				
- Canteen					
	🖓 🍊 K 🔾 🔾 🔿	1/1 🔄 🔂 🖪	lain Report 💌 🏦 👘	Objects	
		Trend	Report for 0101		
			7		
	80 70				
	50 40			· •	
	30				
	20				
	10				
	0 11/14/2008 11/16 8:39PM 4:4	2008 11/17/2008 11/19/2008 11/2 3AM 1:28PM 12:32AM 8:	0/2008 11/21/2008 11/23/2008 17AM 5:07PM 1:00AM	11/25/2008 12/1/2008 12/3/ 6:15AM 3:13PM 4:15	2008 12/4/2008 5AM 12:15PM
		Aug o kop_RpExtTine wolke bit	r Aug of Is ;1 Andex (Ten your sup_Rpice (Ten your sub)	r;15ktTemp	
	ZoneTemperature(°F)	Setpoint Temperature	(°F) Time		
	73	72	11/14/2008 8:39:32PM		
	74	72	11/16/2008 4:43:57AM		
	73	74	11/19/2008 12:32:294	4	
	71	72	11/20/2008 8:17:27AM	1	
	72	73	11/21/2008 5:07:52PM	1	
	71	75	11/23/2008 1:00:39AM	1	
	56	74	11/25/2008 6:15:36AM	1	
	69	74	12/1/2008 3:13:00PM		
	70	70	12/3/2008 4:15:34AM		
	67	75	12/4/2008 12:15:32PM		



View Daily Performance Report

Zone Monitor 1 S	Setup	User Adminis	stration /	Alarm	Schedule	Advanced	Help			
DashBoard Change S	etpoint Reports					۹.				
Daily Performance A	arm After Hour Usa	age Trend								
Node Group	ALL	✓ 3								
From Date	12/15/2008	III 4		5 To Date	12/18/2	2008				
View Report 6				_						
🗿 🍊 H 🗸 🕨	₩ 1/1+	🔄 🛛 Main Rep	ort 💌 🐧	Business Objects						
WPT Daily Performance Report										
Time	Setpoint(°F) Zo	ne Temp(°F) Pr	essure(PSI)	BatteryLevel(%)	Occupancy Override	RoutingInfo				
Date:12/15/2008										
Node ID: 1202	Node Name: PR12-PF	13133								
15 Dec 2008 23:47:33:170	81	4 ()	100	OFF	12 11 01				
15 Dec 2008 23:32:33:170	81	3 ()	100	OFF	12 11 01				
15 Dec 2008 23:17:33:187	81	4 ()	100	OFF	12 11 01				
15 Dec 2008 23:02:33:217	81	(4 L	1	100	OFF	121101				
15 Dec 2008 22:47:33:233 15 Dec 2008 22:32:32:250	01	14 L	,	100	OFF	121101				
15 Dec 2008 22:32:33:250	81	4 0	'n	100	OFF	121101				
15 Dec 2008 22:02:33:263	81	4 0	Ď	100	OFF	12 11 01				



View Alarm Report

Zone Monito	or 1 Setu	p	User Administration	Alarm	Schedule	Advanced Help			
DashBoard	Change Setpo	oint Reports				, P			
Daily Perfe	ormance Alarn	n After Hour Usa	ge Trend						
Node Grou	A La qu	ALL	✓ 4						
Start Date	: 13	2/15/2008	5	End Date	12/18/2008	iii 6			
View Report 7									
p 🗇	н. н. н. н	1/1+	🛃 🛛 Main Report 💌	1 Business Objects					
Alarm Report									
NodelD	NodeName	AlarmVa	ue AlarmStartTime	ACKTime	AlarmEndT	ïme			
Temperatu	ire Alarm								
1107	PR-11 HUB12	72	11/18/2008 9:00:04A	M	11/18/2008	4:45:00PM			
1107	PR-11 HUB12	72	11/17/2008 6:45:02F	°M	11/17/2008	9:00:02PM			
1107	PR-11 HUB12	75	11/17/2008 1:08:01F	°M .	11/17/2008	1:08:01PM			
1107	PR-11 HUB12	75	11/17/2008 1:07:36F	°M	11/17/2008	1:07:41PM			
1107	PR-11 HUB12	75	11/17/2008 1:06:02F	M	11/17/2008	1:06:09PM			
1202	PR12-PR13133	72	11/28/2008 7:32:36A	M	11/28/2008	9:47:36AM			
1202	PR12-PR13133	72	11/28/2008 6:02:40A	M	11/28/2008	6:47:41AM			
1202	PR12-PR13133	72	11/28/2008 4:17:40/	M	11/28/2008	5:17:40AM			
1202	PR12-PR13133	72	11/27/2008 3:17:38F	°M	11/27/2008	3:32:38PM			
1202	PR12-PR13133	72	11/27/2008 11:32:38	AM	11/27/2008	2:17:38PM			
1202	PR12-PR13133	72	11/27/2008 10:17:38	AM	11/27/2008	10:32:38AM			
1202	PR12-PR13133	70	11/24/2008 9:53:38A	M	11/25/2008	11:02:29PM			



After Hour Usage Report

Zone Moni	tor	Setup	User Administr	ation Reports 1	Help	
Daily Perf	formance Al	arm After Hour	Usage 2			
Node Gro	up	3rd Floor	✓ 3			
Start Date	е	11/12/2008	III 4	5 End Date	11/18/2008	
View Re	eport 6			_		
ê 🍯	$H \to H$	H 1/1	🛃 🛛 Main Report 💌 🖄	Business Objects		
			After Hour Usage Repo	ort		
NodelD	NodeName		StartTime	EndTime	Duration(Hrs)	
1302	PR13-PR12		11/28/2008 12:18:06PM	11/28/2008 1:33:06PM	1	
1303	PR13-PR11		11/28/2008 1:03:46PM	11/28/2008 2:31:37PM	1	
1403	PR14-PR12		11/27/2008 1:34:43PM	11/27/2008 4:49:43PM	3	
1404	PR14-PR12		11/27/2008 1:34:43PM	11/27/2008 5:34:44PM	4	



Advanced Features

• WPT LCD Key Lock/Unlock

Zone Monitor	Setup	User Administration	Alarm	Schedule	Advanced 1	Help
Keypad Lock/Unlock	Setpoint Limits Auto	Calibration Archiv	e Command Status			
Command by						
⊙Node 3 €	Node Group					
Node 4 1502	2 🔽 🖌 🖌					
Current Status : U	nlocked Lock 6]				

• Configure Setpoint Limits

Zone Monitor	Setup	User Administration	Alarm	Schedule	Advanced 1	Help
Keypad Lock/Unlock	Setpoint Limits Auto	o Calibration Archive	Command Status			
Command by	2					
⊙Node 3 €	Node Group					
Node 4 160	2 🗸 Go 5					
Current Setpoint Lo	w Limit (°F) N/A	Current Setpoint High	Limit (°F) N/A			
Setpoint Low Limit ((°F) 6	Setpoint High Limit (*	F)			
		Update 7				

• Auto Calibration

Zone Monitor	Setup	User Admini	istration	Alarm	Schedule	Advanced Help
Keypad Lock/Unlock	Setpoint Limits	Auto Calibration	Archive	Command Status		0
Node 3 B103	V Go 4	2				
- Last Calibration-			1			
Setpoint Offset (°F)	N/A				
Date		N/A				
Control Pressure (F	2SI) 5	76	Calculate S	etpoint Offset 6		
Recommended Set	point Offset (°F)	0 Calib	orate 7			

History Data Archival

one Monitor	Setup	User Administration	Alarm	Schedule	Advanced 1	Help
(eypad Lock/Unlock	Setpoint Limits Auto	o Calibration Archive	Command Status			
Backup Database	3	2				



Accessing WPT using BACnet/IP

- Each WPT is represented as a BACnet Device Object
- The WPT device object has following I/O Objects
 - 3xAnalog Input Object (Ambient Temp, Branch Pressure and Battery Level)
 - 1xAnalog Output Object (setpoint)
 - 1xBinary Input Object (Occupancy Override)
- WPT BACnet Gateway is BBMD enabled



Reference Documents

Topics	Reference Document	Document Number	
Features and benefits of WPT	Wireless Pneumatic Thermostat Product Brief	PBWPT080826	
Installing and configuring Battery Powered Repeater	Battery Powered Repeater Installation Instruction	Doc No: 910-00001-01	
Installing and configuring Wall Powered Repeater	Wall Powered Repeater Installation Instruction	Doc No: 910-00002-01	
Installing and configuring USB Hub	USB Hub Installation Instruction	Doc No: 910-00003-01	
Installing and configuring WPT	WPT installation Instruction	Doc No: 910-00005-01	
Estimating the number of repeaters and selecting the optimum location for Repeaters and Hub.	WPT Wireless Network Planning Guide	Doc No: 910-00006-01	
Installing and configuring WPT Web Server	WPT Web Server Installation Instruction	Doc No: 910-00007-01	
BACnet Objects and Properties supported by WPT BACnet Server	WPT BACnet PICS	Doc No: 910-00008-01	
Using the wireless range testers	WPT Wireless Range Tester User Manual	Doc No: 910-00009-01	



Thank you

www.CypressEnvirosystems.com

