



**CYPRESS**  
ENVIROSYSTEMS



## **Wireless Freezer Manual**

### **Installation Guide**

Doc # 152-11103-01  
Revision DRAFT  
May 2009

## Copyrights

Copyright 2008 by Cypress EnviroSystems. All rights reserved.

The information in this document is subject to change without notice. While reasonable precautions have been taken, Cypress EnviroSystems assumes no responsibility for any errors that may appear in this document. No part of this document may be copied or reproduced in any form or by any means without the prior written consent of Cypress EnviroSystems.

## Disclaimer

CYPRESS ENVIROSYSTEMS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Cypress EnviroSystems reserves the right to make changes without further notice to the materials described herein. Cypress EnviroSystems does not assume any liability arising out of the application or use of any product or information described herein. Cypress EnviroSystems does not authorize its products for use in mission or safety critical systems or where a malfunction or failure may reasonably be expected to result in significant injury to the user. The inclusion of Cypress EnviroSystems' product in mission or safety critical system applications implies that the manufacturer assumes all risk of such use and in doing so indemnifies Cypress EnviroSystems against all charges. In no event is Cypress EnviroSystems liable to anyone for any indirect, special or consequential damages.

## Table of Contents


1.0	Introduction .....	4
2.0	Safety Precautions .....	5
3.0	Components.....	5
4.0	Tools Required .....	5
5.0	Workflow .....	6
6.0	Installation .....	7
6.1	Access the Freezer .....	7
6.2	Locate the WFM.....	7
6.3	Connect the Sensors .....	7
6.4	Mount and Connect the Antenna.....	7
6.5	Connect the Terminal Strips .....	8
6.6	Configure the WFM Channel Set .....	8
6.7	Configure the WFM on the BBS.....	9
6.8	Perform Functional Test .....	14
6.9	Restore the As-Found Condition of the Freezer .....	15
7.0	Battery Life.....	15
8.0	Troubleshooting.....	15
9.0	Technical Specifications .....	15
10.0	Product Disposal .....	16
11.0	Support .....	16
12.0	Warranty Information.....	16

## 1.0 Introduction


Thank you for purchasing this Wireless Freezer Monitor, WFM. Please read this guide thoroughly before installing the WFM.

The Cypress EnviroSystems Wireless Freezer Monitor, WFM, is designed to monitor the operating condition of a freezer. This is achieved by monitoring compressor amperage, chamber temperature, and door switch status of a freezer and transmitting the data to a PC, or data acquisition system. The WFM can be either AC or DC powered. Installation is designed to be minimally invasive.

The following diagram describes the various components of the WFM.



- A. Sensor input terminal strip
- B. External power terminal strip
- C. LED Indicators
- D. 5V-48V barrel jack input, 5.0mm x 2.1mm
- E. Function Button
- F. Radio 1 antenna connector
- G. Programming/Expansion port



## 2.0 Safety Precautions

- Do not immerse the WFM in water.
- Always wear personal protective equipment appropriate to the system the WFM is being installed on.
- Do not try to repair the WFM yourself as it contains no user-serviceable parts. Contact a qualified service technician for repairs. See Section 11.0, Support, for details.

## 3.0 Components

The WFM comes with the following components:



WFM



Antenna, with cable



Power cord (optional)



Thermocouple



External power  
connector



Sensor input connector



Clamp-on ammeter




Crimp connector

## 4.0 Tools Required

- Screwdriver (to access the mechanical space of the freezer)
- 3/32" Flat-head Screwdriver
- Cable Ties
- Compression Pliers for #24 to #28 wire splices

## 5.0 Workflow



## 6.0 Installation

### 6.1 Access the Freezer

In order to monitor the freezer, sensors must be installed on various components within the freezer. This requires that the installer locate the compressor motors and existing door switch for the freezer.

Access the freezer by removing the panels on the back and side of the freezer, exposing the mechanical space. For some models, the mechanical space is on top of the freezer.

### 6.2 Locate the WFM

Find a secure location for the WFM in the mechanical space of the freezer. This will ensure that the WFM is out of the way of everyday users. When finding a location for the WFM, make sure that the sensors can still be connected to the WFM.

### 6.3 Connect the Sensors

#### 6.3.1 Compressor Ammeters

For safety reasons, the freezer should be unplugged prior to making any connections to the freezer.

1. Locate the compressors in the mechanical space of the freezers.
2. Identify which compressor is the high stage and low stage. Most times the compressors are marked with an "H" or "L" identifier. If the compressors are not marked, connect the ammeters and identify the correct compressor during the functional test. Typically, the low stage compressor starts first.
3. Identify the power legs of each compressor. Connect the ammeter to the negative side of the power legs.
4. The high stage compressor ammeter positive wire (white) connects to OPT2, the negative wire (black) connects to ground on the WFM terminal strip.
5. The low stage compressor ammeter positive wire (white) connects to OPT1, the negative wire (black) connects to ground on the WFM terminal strip.

#### 6.3.2 Thermocouple

1. Determine the path to route the thermocouple into the freezer chamber. Use cable fasteners to secure the thermocouple, as required.
2. Route the closed end of the thermocouple into the freezer chamber.
3. Connect the two-wire end of the thermocouple to the WFM. The yellow wire connects to CH1+ on the WFM terminal strip. The red wire connects to CH1- on the WFM terminal strip.

#### 6.3.3 Door Switch

For safety reasons, the freezer should be unplugged prior to making any connections to the freezer.

1. Determine if the freezer has a door alarm. If so, the door switch alarm can be connected.
2. Locate the freezer door switch contact wires. If the freezer has two doors, determine which door the owner wants to alarm.
3. Use the crimp connector and compression tool to connect the door switch contact wires. The higher potential of the two door contact wires should be connected to Ch2+ on the WFM terminal strip.

### 6.4 Mount and Connect the Antenna









1. The external antenna is magnetic. The best location for the antenna is the upper back corner of the freezer. Find a path from the antenna location to the WFM.
2. Route the extension wire and connect it to the WFM.
3. Connect the antenna.

## 6.5 Connect the Terminal Strips

Plug in the two terminal strips. If the WFM is battery operated, ensure that the batteries are installed. If the WFM is AC powered, route the power cord to a power outlet.

## 6.6 Configure the WFM Channel Set

### 6.6.1 Connect the WFM to the HH Device

1. Turn on the WFM by connecting the power terminal strip. If the WFM is AC powered, make sure the unit is plugged in.
2. Transition the WFM into Configuration Mode: Hold the Function button for approximately 6 seconds. The green light, yellow light, and red light will turn on in series, then flash rapidly. Release the function button and the green light will blink continuously.
3. Remove the HH Device from its Docking Station
4. Power on the HH. Press and hold the **[Enter/On]** key for one second. When the **Green LED** flashes, release the **[Enter/On]** key.
5. Launch the HH application: Select the Windows Start Icon on the top left of the Touch Screen , Select the HH Control application from the Start Menu .
6. Bind to WFM: Select the Name ID Tab , press the Find Button . Wait for the HH to search for all WFMs in the vicinity that are in Configuration mode.
7. The HH will list all WFMs and their Device ID it finds. Select the WFM you want to configure based on the Device ID .
8. Assign a Device Name (if not already assigned) by tapping on the name twice until it is in text entry mode . Enter a name and press Bind . The Bnd column should convert to "Y" from "N" .

### 6.6.2 Configure WTR using the HH

The following parameters must be setup using the HH to configure a WFM.

WFM Parameter	Parameter in HH	Function
Node ID	Node ID	The Node ID of the WFM
RF Frequency A	RF Frequency A	Wireless communication Frequency A of the WFM
RF Frequency B	RF Frequency B	Wireless communication Frequency B of the WFM
Sample Rate	Sample Rate (sec)	Update rate of the WFM while in Normal Mode (seconds)
Channel 1 Setup	Radius 1	Channel configuration – See channel setup
Channel 2 Setup	Radius 2	Channel configuration – See channel setup
Channel 3 Setup	Radius 3	Channel configuration – See channel setup
Channel 4 Setup	Radius 4	Channel configuration – See channel setup

Notice the WFM parameter name is not used in the HH parameters list. Channel 1-4 setup will be done under Radius 1-4. All other fields should be 0. The table above shows the mapping between the two.



The following table lists the channel setup values.

Channel Setup	Type
0	Channel is off – not used
1	Normal voltage/current sensing (which one depends on hardware)
2	Thermistor (not used for WFM)
3	Sample RS232 LR300's ch1 (not used for WFM)
4	Sample RS232 LR300's ch2 (not used for WFM)
5	Sample RS232 LR300's ch3 (not used for WFM)
6	Sample RS232 LR300's ch4 (not used for WFM)
7	Sample RS485 LR300's ch1 (not used for WFM)
8	Sample RS485 LR300's ch2 (not used for WFM)
9	Sample RS485 LR300's ch3 (not used for WFM)
10	Sample RS485 LR300's ch4 (not used for WFM)
11	Thermocouple
12	Switch

- Channel 1 – Thermocouple ONLY. Value = 11
- Channel 2 – Switch ONLY. Value = 12
- Channel 3 – Voltage ONLY. Value = 1
- Channel 4 – Voltage ONLY. Value = 1

## 6.7 Configure the WFM on the BBS

Navigate to the Node Config page and enter the Device ID of the node you wish to add. The node ID for each channel will increment as follows. The example assumes that the WFM Device ID is 150.

Device ID	Node ID	Channel Description
150	150	Low-side compressor current sensor
150	151	High-side compressor current sensor
150	152	Internal freezer temperature sensor
150	153	Freezer door sensor



## Cypress Systems Console

### WGR Nodes Configuration

NodeID	<input type="text" value="150"/>	<input type="button" value="Add..."/>	
		<input type="button" value="Delete"/>	

Edit	NodeID	DeviceID	Description	Units	MinValue	MaxValue	LCL	UCL	SMSAlarm	AlarmCtrl	Limit	Precision	NodeDetail
<a href="#">Edit</a>	1	1	B1_S1_BAT1_VOLT	mV	0	1	0	2	<input type="checkbox"/>	1			
<a href="#">Edit</a>	2	2	B1_S1_BAT1_TEMP1	C	0	1000	10	90	<input type="checkbox"/>	3	0		
<a href="#">Edit</a>	3	3	B1_S1_BAT1_CUR	A	0	1	0	2	<input type="checkbox"/>	3	0		
<a href="#">Edit</a>	4	4	B1_S1_BAT1_RES	uOhm	0	100	10	90	<input type="checkbox"/>	3	1		

Enter the Device ID of the WTR and click Add.

### Node Configuration Dialog

NodeID	<input type="text" value="150"/>	Device ID	<input type="text" value="150"/>	<input type="button" value="Ok"/>
Name	<input type="text" value="WTR150 Low Side Comp. Current"/>			<input type="button" value="Close"/>
Unit	<input checked="" type="radio"/> Units <input type="text" value="A"/> <input type="radio"/> Binary <input type="text" value="0-TRUE/FALSE"/>			
Decimal Precision	<input type="text" value="1"/>	<input type="checkbox"/> Enable Verify Node		
<input type="checkbox"/> Node Math function <input type="text"/> <input type="button" value="-"/> <input type="button" value="v"/>				
<input type="checkbox"/> Enable Alarm      Alarm Excursion # <input type="text"/>				
Alarm Thresholds Min <input type="text" value="10"/> Max <input type="text" value="90"/>				
<input type="radio"/> WGR Configuration      Min <input type="text"/> Max <input type="text"/>				
<input checked="" type="radio"/> WTR Configuration <input type="checkbox"/> Log Scale      Sensor Type <input type="text" value="OPT1-2"/>				
<input checked="" type="checkbox"/> Sensor Responsibility				
Volts or mA 1		<input type="text" value="0"/>	Value1	<input type="text" value="0"/>
Volts or mA 2		<input type="text" value="5"/>	Value2	<input type="text" value="20"/>
<input type="checkbox"/> One Point Calibration				
		Value Measured	<input type="text"/>	
		Value Desired	<input type="text"/>	
		Cold Junction	<input type="text"/>	

Node ID 150: Configure the low side current sensor. Enter the sensor units [A] for amps. Select the sensor input type. For the current sensors, this will be [OPT 1-2]. Enter the sensor responsivity. This number is typically found in the datasheet; for the clamp on current sensors, it is 0-5V for an input of 0-20A.

## Node Configuration Dialog

NodeID	151	Device ID	150	Ok
Name	WTR150 High Side Comp. Current			Close
Unit	<input checked="" type="radio"/> Units <input type="radio"/> Binary			
	A 0-TRUE/FALSE			
Decimal Precision	1	<input type="checkbox"/> Enable Verify Node		
<input type="checkbox"/> Node Math function				
<input type="checkbox"/> Enable Alarm      Alarm Excursion #				
Alarm Thresholds				
Min	10			
Max	90			
<input type="radio"/> WGR Configuration      Min      Max				
<input checked="" type="radio"/> WTR Configuration <input type="checkbox"/> Log Scale      Sensor Type      OPT1-2				
<input checked="" type="checkbox"/> Sensor Responsivity				
Volts or mA 1	0	Value1	0	
Volts or mA 2	5	Value2	20	
<input type="checkbox"/> One Point Calibration				
		Value Measured		
		Value Desired		
		Cold Junction		

Node ID 151: Configure the high side current sensor. Enter the sensor units [A] for amps. Select the sensor input type. For the current sensors, this will be [OPT 1-2]. Enter the sensor responsivity. This number is typically found in the datasheet; for the clamp on current sensors, it is 0-5V for an input of 0-20A.

## Node Configuration Dialog

NodeID	152	Device ID	150	Ok
Name	WTR150 Freezer Temp			Close
Unit	<input checked="" type="radio"/> Units <input type="radio"/> Binary			
	C			
	0-TRUE/FALSE			
Decimal Precision	1	<input type="checkbox"/> Enable Verify Node		
<input type="checkbox"/> Node Math function	<input type="text"/> - <input type="text"/>			
<input type="checkbox"/> Enable Alarm      Alarm Excursion # <input type="text"/>				
Alarm Thresholds				
Min	10			
Max	90			
<input type="radio"/> WGR Configuration      Min <input type="text"/> Max <input type="text"/>				
<input checked="" type="radio"/> WTR Configuration <input type="checkbox"/> Log Scale      Sensor Type <input type="text" value="Thermocouple Type-K"/>				
<input type="checkbox"/> Sensor Responsivity				
Volts or mA 1	<input type="text"/>	Value1	<input type="text"/>	
Volts or mA 2	<input type="text"/>	Value2	<input type="text"/>	
<input type="checkbox"/> One Point Calibration				
	Value Measured	<input type="text"/>		
	Value Desired	<input type="text"/>		
	Cold Junction	<input type="text"/>		

Node ID 152: Configure the freezer thermocouple temp sensor. Enter the sensor units [C] for Celsius. Select the sensor input type. For the thermocouple, this will be [Thermocouple Type-K]. The sensor responsivity field is not needed for this sensor.

## Node Configuration Dialog

NodeID	153	Device ID	150	Ok
Name	WTR150 Freezer Door			Close
Unit	<input type="radio"/> Units <input checked="" type="radio"/> Binary			
	2-ACTIVE/INACTIVE			
Decimal Precision	0	<input type="checkbox"/> Enable Verify Node		
<input type="checkbox"/> Node Math function		-		
<input type="checkbox"/> Enable Alarm      Alarm Excursion # <input type="text"/>				
Alarm Thresholds				
Min	0			
Max	1			
<input type="radio"/> WGR Configuration      Min <input type="text"/> Max <input type="text"/>				
<input checked="" type="radio"/> WTR Configuration <input type="checkbox"/> Log Scale      Sensor Type OPT1-2				
<input type="checkbox"/> Sensor Responsivity				
Volts or mA 1	<input type="text"/>	Value1	<input type="text"/>	
Volts or mA 2	<input type="text"/>	Value2	<input type="text"/>	
<input type="checkbox"/> One Point Calibration				
		Value Measured	<input type="text"/>	
		Value Desired	<input type="text"/>	
		Cold Junction	<input type="text"/>	

Node ID 153: Configure the freezer door sensor. Select binary for unit type. In the pulldown box, select open/closed as the binary states. The other information on the page has no effect on the binary sensor.

## Node Configuration Dialog

NodeID	152	Device ID	150	Ok
Name	WTR150 Freezer Temp			Close
Unit	<input checked="" type="radio"/> Units    C <input type="radio"/> Binary    0-TRUE/FALSE			
Decimal Precision	1	<input type="checkbox"/> Enable Verify Node		
<input type="checkbox"/> Node Math function	<input type="text"/> - <input type="text"/> <input type="text"/>			
<input type="checkbox"/> Enable Alarm    Alarm Excursion # <input type="text"/>				
<b>Alarm Thresholds</b> Min <input type="text"/> 10 Max <input type="text"/> 90				
<input type="radio"/> WGR Configuration    Min <input type="text"/> Max <input type="text"/>				
<input checked="" type="radio"/> WTR Configuration <input type="checkbox"/> Log Scale    Sensor Type: Thermocouple Type-K				
<input type="checkbox"/> Sensor Responsivity				
Volts or mA 1 <input type="text"/>		Value1 <input type="text"/>		
Volts or mA 2 <input type="text"/>		Value2 <input type="text"/>		
<input checked="" type="checkbox"/> One Point Calibration		Value Measured <input type="text"/> -72.5		
		Value Desired <input type="text"/>		
		Cold Junction <input type="text"/> 25.6		

Thermocouple Temperature Calibration: If the displayed temperature differs from the desired temperature, a correction can be made by selecting One Point Calibration and entering the value desired. The Value Measured and Cold Junction temperatures are populated with the latest readings.

## 6.8 Perform Functional Test

With the WFM configured and recording, test the inputs to the freezer.

### 6.8.1 Door Switch

- Open the freezer door to trigger the door switch.
- Press the function button on the WFM to collect a reading.
- Confirm that the door status is correct; ensure that the door is open when the switch says open. If the switch is backwards, return to the Node Config page and change the Open/Close or Close/Open binary option.
- Repeat the test to confirm proper operation of the door switch.

### 6.8.2 Thermocouple

- Check the temperature reading, and confirm it is consistent with the freezer temperature.
- Place your fingers over the thermocouple to change the temperature.
- Press the function button on the WFM to collect a reading.
- Confirm that the temperature reading changed.

### 6.8.3 Current Sensors

- Check the current readings.

- Allow the freezer to cycle. This may take some time (1/2 hour). If the freezer does not cycle in a reasonable period of time, open the freezer door to create a temperature change in the chamber.
- As the freezer cycles, verify that the low stage compressor turns on first, then the high stage compressor.

## 6.9 Restore the As-Found Condition of the Freezer

Once the WFM functionality has been verified, close any open freezer panels and put the freezer back in place.

## 7.0 Battery Life

If you are using a battery powered WFM, the battery status of the WFM can be monitored through the web console. Battery change-out must be performed by a qualified service technician. See Section 10.0, Support, for details.

The battery life of the WFM is dependent on the sampling frequency. Typical ranges are listed below.

Sampling Frequency	Estimated Battery Life
1 sample per 1 minute	1.5+ years
1 sample per 15 minutes	2.5+ years
1 sample per hour	3+ years
1 sample per day	3+ years

## 8.0 Troubleshooting

## 9.0 Technical Specifications

Analog Data Inputs:	User-configurable: Typically internal temperature, door switch, high side compressor current, low side compressor current
Number of Inputs:	Up to four inputs per WFM
Data Capture Rate:	User-configurable
Thermocouple:	Type K, -328°F to 482°F (-200°C to 250°C)
Current Sensor:	Standard: Split core, 0-20A DC. Other current sensors available upon request.
Wireless Frequency:	2.4GHz Direct Sequence Spread Spectrum, 100mW peak output
Wireless Range:	Up to 1600 ft (488 m), high interference immunity, extendable with repeaters
Wireless Protocol:	Cypress Semiconductor's highly optimized industrial DSSS radio and protocol. Integrates robust security, antenna and frequency diversity, optional encryption and minimal interference with existing wireless systems (for additional details, please see FAQ at <a href="http://www.cypressexvirosystems.com">www.cypressexvirosystems.com</a> )
Approvals:	FCC Class B compliant, RoHS, ETSI compliant
Power Supply:	Standard 110-240VAC or battery powered
Battery Life:	>3 years (approximate)
Humidity:	10-99%RH, non-condensing
Operating Temperature:	-4°F to 158°F (-20°C to 70°C)
Storage Temperature:	-40°F to 185°F (-40°C to 85°C)
Enclosure:	Rugged extruded aluminum industrial chassis (optional NEMA4/IP66 enclosure)

Dimensions: 5.7" x 2.2" x 1.6" (145mm x 57mm x 42mm)  
Weight: 0.51 lbs (230g)

## 10.0 Product Disposal

The WFM is recycled by Cypress EnviroSystems. Contact a service technician or Cypress EnviroSystems headquarters to recycle the WFM. See Section 10.0, Support, for details.

## 11.0 Support

For additional support, including configuration, maintenance, and troubleshooting, please contact us.

Cypress EnviroSystems  
198 Champion Court  
San Jose, CA 95134  
+1 888 987 3210  
Email: [cys\\_support@cypress.com](mailto:cys_support@cypress.com)

## 12.0 Warranty Information

Every product comes with a full one-year parts and labor warranty. Cypress EnviroSystems monitoring of battery status, product status, and potential communications packets are included during this period, so that proactive service can be provided to our customers.