

WPT Server software

Installation Manual – Upgrade to Version 19.0.2

Purpose

This document will guide the installer to upgrade the WPT host application from Version 17.0 or 18.1 to 19.0.2

Host Application Installation

1. Close the USBReader application (if running).
2. Unzip the WPT_HostApp_V19.0.2_Upgrade
3. Execute WPT_HostUpgrade.bat
4. Wait for the batch file to complete the execution. (Some error messages are normal, depending on prior version)
5. This completes the upgrade.
6. The installation log file will be created at C:\WPT\WPT_Upgradelog.txt
7. Remember to enable and execute Windows Update to get the latest security patches if necessary from \windowsupdate folder.
8. Remember to enable the PGandEListenerService for any Auto-DR customer
9. Remember to enable the BACnetServer for any BACnet-connected customer
10. Reboot the machine for change to take effect.